

**READ THIS FIRST:**

Read and follow all instructions carefully before beginning installation.

**LISEZ CECI EN PREMIER:**

Lire et suivre toutes les instructions attentivement avant le montage.

**LEA ESTO PRIMERO:**


Lea y siga todas las instrucciones cuidadosamente antes de iniciar la instalación.

# Installation Instructions

## Instrucciones de instalación

### Directives de montage

## Towing Vehicle 4-way Flat Plug

**TOWING VEHICLE:**

1. Locate the appropriate wires at rear of vehicle using circuit tester and the chart as a reference.
2. Make the connections as shown using wire taps.
3. Connect the Ground wire (White) to the vehicle frame or body.

**GENERAL:**

1. Test all lights.
2. Secure all loose wires.

**NOTE:**

- Vehicles with separate turn and stop lights require a taillight converter.
- If splicing into the vehicle wiring, check the vehicle owner's manual and/or local dealer for any warnings or restrictions before splicing. When splicing use appropriate gauge wire splices.

**WARNING**

All connections must be complete to function properly. Test and verify installation with a test light, circuit tester or trailer once installed.

**WARNING**

Overloading circuit can cause fires. **DO NOT** exceed lower of towing manufacturer rating or:

- Max. Right Turn, Left Turn, Stop, & Tail Light Circuits: (7.5 amps)
- Max. (+) Battery, Reverse, and Electric Brake Circuits: (30 amps)

Read vehicle's owners manual & instruction sheet for additional information.

Additional fusing may be required.